


TimberWhite + Top Coat

SYSTEM INFORMATION

- **TimberWhite basecoat** (intumescent) + Resene Spacecoat Low Sheen Waterborne Enamel (top coat)
- Fireshield timber intumescent system for **C1 interior zones** on interior timber battens, wall and ceiling linings.
- Achieves **Group 1 Surface Rating** to timber substrates. See Fireshield for C2 and C3 (ISO 12944-2) interior environments, areas where constant air humidity is over 75%.
- Only to be applied by Registered Applicators in accordance with Fireshield Application Instructions, TDS and MSDS.



System Name	TimberWhite-AU-01-C1
ISO 9223:2012 Zone	C1 Interior (Heated buildings with clean atmospheres, e.g. offices, shops, schools, hotels)
Substrate	Interior timber substrates $\geq 8\text{mm}$ thick + $\geq 338 \text{ kg/m}^3$ density. See TDS for full requirements.
TimberWhite + Top Coat System Description	<p>Fireshield® TimberWhite is a single component, waterbased pigmented white intumescent basecoat for the fire protection of interior timber.</p> <p>When a washable surface is required, or the humidity levels temporarily exceed 75% it is advisable to apply Resene Spacecoat Low Sheen Waterborne Enamel top coat over the TimberWhite coating.</p>

COATING SYSTEM

COAT	PRODUCT	TDS CODE	THINNER	APPLICATION	FILM BUILD	Clean Up
First Coat	TimberWhite intumescent basecoat	TD-FSTWAU-02	DO NOT THIN	Spray	Minimum 310 microns WFT (215 microns DFT)	Water
Second Coat	Resene Spacecoat Low Sheen Waterborne Enamel Top Coat	D311	Water	Spray or roll	37 microns DFT	Water

SURFACE PREPARATION

All surfaces to be coated should be clean, dry and free from contamination including dirt, salts, oil and grease. If required, clean as per AS/NZS 2311 Sec 3.2.7, any contaminant left on the surface will affect the visual appearance of the Fireshield® timber ICS system. Timber must be allowed to equilibrate in a location protected from the weather to near its final in-service conditions, to avoid shrinkage or swelling after installation and coating. Dressed timber should be smooth, and free from raised or woolly grain, planing burrs, or other machining defects. The standard of finish should be appropriate to the end-use (see NZS 3610 and NZS 3617). Rough-sawn timbers should be thoroughly brushed with the grain to remove dust and dirt before coating.

* Spray application is always recommended, if application is by brush or roller, further coats may be necessary to achieve the recommended DFT.

** WFT is thickness of wet paint required to achieve the specified 'Dry Film Thickness' assuming no thinner is added.